

DIY Frame Cut List for Regular leg

Single Twin Bed (Mattress size 39" x 75" x 10" thickness) **NO FOAM or BLOW UPS**

Overall Cabinet Dimension: 44 7/8" W x 81" H x 15 7/8" D Protrusion from wall to foot bed: 85 1/2"				
# of pieces	Description	Width	Length	Material
2	Side Panels	15 7/8"	81"	3/4" Plywood
1	Headboard	14 7/8"	43 3/8"	"
1	Top Stretcher	14 7/8"	43 3/8"	"
1	Bottom Stretcher	6"	43 3/8"	"
1	Kick	1 7/8"	43 3/8"	"
1	Bed Panel	43"	78 1/4"	"
2	Side Rails	4 1/2"	75 3/4"	"
2	End Rails	4 1/2"	41 1/8"	"
2	Side Cleats	3/4"	74 1/4"	3/4" x 3/4" Solid
2	End Cleats	3/4"	39 5/8"	"
2	Leg Stops	1 1/8"	2"	3/4" ply or solid
1	Leg Crossbar	1" Dia	41 13/16"	Hardwood Dowel

Double/Full Bed (Mattress size 54" x 75" x 10" thickness) **NO FOAM or BLOW-UPS**

Overall Cabinet Dimension: 59 7/8" W x 81" H x 15 7/8" D Protrusion from wall to foot bed: 85 1/2"				
# of pieces	Description	Width	Length	Material
2	Side Panels	15 7/8"	81"	3/4" Plywood
1	Headboard	14 7/8"	58 3/8"	"
1	Top Stretcher	14 7/8"	58 3/8"	"
1	Bottom Stretcher	6"	58 3/8"	"
1	Kick	1 7/8"	58 3/8"	"
2	Bed Panel	29"	78 1/4"	"
1	Stiffener	6"	74 1/4"	"
2	Side Rails	4 1/2"	75 3/4"	"
2	End Rails	4 1/2"	56 1/8"	"
2	Side Cleats	3/4"	74 1/4"	3/4" x 3/4" Solid
2	End Cleats	3/4"	54 5/8"	"
2	Leg Stops	1 1/8"	2"	3/4" ply or solid
1	Leg Crossbar	1" Dia	56 3/4"	Hardwood Dowel

Queen Bed (Mattress size 60" x 80" x 10" thickness) **NO FOAM or BLOW-UPS**

Overall Cabinet Dimension: 65 7/8" W x 86" H x 15 7/8" D Protrusion from wall to foot bed: 90 1/2"				
# of pieces	Description	Width	Length	Material
2	Side Panels	15 7/8"	86"	3/4" Plywood
1	Headboard	14 7/8"	64 3/8"	"
1	Top Stretcher	14 7/8"	64 3/8"	"
1	Bottom Stretcher	6"	64 3/8"	"
1	Kick	1 7/8"	64 3/8"	"
2	Bed Panel	32"	83 1/4"	"
1	Stiffener	6"	79 1/4"	"
2	Side Rails	4 1/2"	80 3/4"	"
2	End Rails	4 1/2"	62 1/8"	"
2	Side Cleats	3/4"	79 1/4"	3/4" x 3/4" Solid
2	End Cleats	3/4"	60 5/8"	"
2	Leg Stops	1 1/8"	2"	3/4" ply or solid
1	Leg Crossbar	1" Dia	62 3/4"	Hardwood Dowel