

FUJIOH KITCHEN VENTILATING  
APPLIANCE  
INSTALLATION INSTRUCTIONS FOR  
WOOD HOOD AND POWER UNIT

**LINER**

1. Scribe a line (B) distance from top of adjacent cabinets. Position wood filler blocks flat on side of adjacent cabinets above scribe

lines between frame stiles and rear wall and securely fasten to cabinets see Fig. 1.

2. Position liner so that bottom edge is level with scribed lines and drive #8 screws through holes in the liner. Screw length should be

such that firm attachment through blocks and into cabinet is accomplished. Repeat on other side. Liner should now appear as in

Fig. 2.

3. If possible, locate wall studs, drill holes through back of liner and attach to wall securely.

4. Metal liner should also be fastened to skirt of hood after it is hung into place.

**Ventilator Power Unit**

1. Make sure electrical power is turned off at fuse box. Start duct run and electrical cable from soffit or wall.

2. Remove aluminum mesh filter.

3. Remove the front panel (four screws)

4. With the four mounting screws (in packet) mount Fujioh ventilator so that the four screws go thru holes in the Fujioh Ventilator

unit and the liner. Attach four nuts provided, securing tightly.

5. Connect duct run to damper collar. Seal all joints with furnace tape to prevent air leaks and rattles. Be sure damper shutter, if used, is operating freely.

6. Run power supply cable into Fujioh ventilator compartment through knock out, secure with cable connector nuts (not furnished).

7. Connect power line to black leads, power line 2(ground) to white leads with wire nuts (not furnished). Replace wiring

compartment cover.

8. Insert light bulb into lamp receptacle,

9. Reinstall blower front panel by attaching it to the four weld studs using four screws (removed in step3).

10. Reinstall the aluminum mesh filter.

**WOOD HOOD**

1. Slide wood hood into opening between wall cabinets over metal liner. Wood frame on front of hood should be flush with frames of adjoining cabinets.

2. Drill top and bottom holes through the front frames of the adjoining wall cabinets. Drive #6x2 1/2" screws through holes into wood hood fastening it into place. Drive three #8x3/8" screws through front of metal liner into back of wood hood front to attach

liner securely, Installation should now appear as in Fig. 3.

Your Fujioh ventilation system is now ready for operation. Turn electrical current back on and follow procedures as outlined in the units operation manual.

Your installation is now complete. If you should require service or replacement parts on your ventilation system, contact: Fujioh at 1-8888-547-9880

